

**Instruction Manual  
Beckhoff CNC with XENAX® Xvi for  
EtherCAT® and TwinCAT® 3**

Version 2.4

Edition 26. May 2021



**EtherCAT®**

XENAX® Ethernet servo controller with  
EtherCAT® Busmodul

Functional Safety, TÜV certified  
Force processes with „Force Limitation“,  
„Force Monitoring“ and „Force Control“

**Beckhoff TwinCAT, the open PC software  
solution for PLC with NC and CNC Kernels  
for realtime interpolation of the XENAX®  
Xvi servo controller with EtherCAT  
technology.**

## General

This instruction manual describes the integration of the XENAX® servo controller with EtherCAT bus modules in a Beckhoff system with TwinCAT® Version 3 for CNC.

This manual describes only the use of the XENAX® with the internal library of TwinCAT® 3. The internal library must be taken for CNC Configurations and is recommended for experienced users.

Furthermore, the parametrization of LINAX®, ELAX® and ROTAX® motors is shown in this document.

XENAX® can be simply and quickly operated with the intuitive graphical user interface WebMotion®.

We will gladly answer any questions you may have or provide you with additional information.

Alois Jenny  
Jenny Science AG

## Contents


<b>1 Development Environment</b>	<b>4</b>
1.1 Beckhoff	4
1.1.1 Programmable Logic Controller	4
1.1.2 TwinCAT® Version 3	4
1.2 Jenny Science	5
1.2.1 XENAX® servo controller	5
1.2.2 LINAX® Linear motors	5
1.2.3 ELAX® Linear motor slides	5
1.2.4 ROTAX® Rotary motor axes	5
1.2.5 WebMotion	6
1.3 Status LED's of EtherCAT bus module	6
1.4 Additional Material	6
1.5 Software Requirements	6
1.6 Cabeling	7
<b>2 TwinCAT® CNC Configuration</b>	<b>8</b>
2.1 Create Project	8
2.2 ESI XML Installation	9
2.3 Choose Target System	9
2.4 Scan for Devices	10
2.5 Set Cycle Time	10
2.6 Add CNC Channel	11
2.7 PDO-Mapping	12
2.7.1 Required PDO Configuration	12
2.7.2 Add PDO "Modes of Operation"	12
2.7.3 Add PDO "Modes of Operation Display"	13
2.7.4 Link the added PDO's	13
2.8 Axis Parameter Configuration	14
2.9 Jerk Value Conversion	16
2.10 Demo Project	16
<b>3 Replacing Xvi 75V8 by Xvi 75V8S</b>	<b>17</b>
3.1 ESI XML Installation	17
3.2 Change Type	17

## 1 Development Environment

### 1.1 Beckhoff

#### 1.1.1 Programmable Logic Controller

Beckhoff control technology is scalable – from Industrial PCs to PLCs – and can be accurately adapted to your application. The automation software integrates real-time control with PLC, NC and CNC functions.



#### 1.1.2 TwinCAT® Version 3

In order to program Beckhoff PLCs the development software for automation TwinCAT® 3 is required. TwinCAT® 3 uses the Visual Studio Framework and all explanations in this instruction manual are based on it.



## 1.2 Jenny Science

### 1.2.1 XENAX® servo controller

XENAX® servo controller for Jenny Science Axis with integrated EtherCAT® bus module. The bus module is optional but it is required for this application. One XENAX® can control one axis. The XENAX® servo controller recognises all Jenny Science motors and configures the parameters correctly.



### 1.2.2 LINAX® Linear motors


The LINAX® linear motor axes are highly modular and can be flexibly combined amongst each other. Four different series are available.

- Lxc = compact
- Lxu = universal
- Lxs = shuttle
- Lxe = exclusive



### 1.2.3 ELAX® Linear motor slides


Specifically designed for handling and Pick and Place tasks with strokes from 30mm up to 150mm. The configuration is extremely modular and there is only one cable to the XENAX® servo controller.



### 1.2.4 ROTAX® Rotary motor axes

Specifically designed for fast and precise assembly and handling tasks. It can be equipped with standard gripping tools which enables a 360° rotation and has a hollow shaft feedthrough for vacuum or compressed air.

- Rxvp = vacuum pressure
- Rxhq = high torque



### 1.2.5 WebMotion

This is the graphical user interface from Jenny Science. It is stored in the embedded Web server of the XENAX® servo controller.

WebMotion® is launched with a web browser by entering the corresponding TCP/IP address of XENAX®.

LINAX® linear motor axes, ELAX® linear motor slides or ROTAX® rotary motor axes are automatically recognized. The corresponding controller parameters are saved and loaded automatically. With the Quick Start button, the linear motors can operate immediately. No user manual is needed.


Before the XENAX® controller can be used with the Beckhoff PLC via EtherCAT®, a set-up must be made via WebMotion®. This includes the set-up of a payload, soft limits, etc.

For further information on the set-up of a linear motor axis please refer to the instruction manual or the tutorial video that can be found on

<https://www.jennyscience.ch/en/applications/videos>.



### 1.3 Status LED's of EtherCAT bus module



LED Status	RUN	ERR	ST1 (Jenny Science specific)	ST2 (Jenny Science specific)
<OFF>	Initialisation state or no power	Bus module operable	-	Bus module ready
<ON>	Operational state	State bus off	No application in the flash	-
<BLINK>	Pre-operational state	Internal Eeprom blank	-	Protocol download in progress

### 1.4 Additional Material

The following data is needed for a successful operation of the XENAX® servo controller with a EtherCAT bus module:


Filename	Description
Xenax_EtherCAT_Xvi_.xml	Jenny Science ESI-File/XML device description for TwinCAT. The ESI-file can be downloaded on our website <a href="http://www.jennyscience.ch">www.jennyscience.ch</a> „XENAX® Servo controller“ and „Firmware Bus Module“
CANopen Ethernet Manual_.pdf	Manual describes the CANopen communication profile CiA DS301 as well as the device profile CiA DS402 including all available parameters.

### 1.5 Software Requirements

Software	Version
TwinCAT® 3 Automation Software	3.1.4020.0 or later
XENAX Firmware	V4.12 or later
EtherCAT Bus-Module	V2.62 or later

1.6 Cabeling

The EtherCAT bus is connected with the XENAX® servo controller (IN/OUT). For easy commissioning and maintenance, a TCP/IP connection to each servo controller is recommended for access to the WebMotion®.



## 2 TwinCAT® CNC Configuration


This chapter describes the configuration of a Beckhoff TwinCAT® with CNC Kernel to communicate with the XENAX® Xvi servo controllers via EtherCAT.

### HINT:


For correctly setting up the CNC Kernel additional libraries and the Beckhoff HMI are required. The CNC Kernel was developed by ISG Industrielle Steuerungstechnik GmbH and a detailed documentation can be downloaded at: <https://www.isg-stuttgart.de/en/isg-kernel/kernel-downloads.html>

### 2.1 Create Project

File → New → Project...




Create a new TwinCAT XAE Project.




## 2.2 ESI XML Installation

The EtherCAT Slave Information XML for the XENAX should always be completely unpacked into the ESI-directory of the EtherCAT Master. In TwinCAT 3 these files are located in `\TwinCAT\3.1\Config\Io\EtherCAT`. This ESI file can be downloaded from [www.jennyscience.ch](http://www.jennyscience.ch) under "XENAX Servocontroller->Firmware Bus Module->EtherCAT".




Load ESI file into TwinCAT. "TwinCAT->EtherCAT Devices->Reload Device Descriptions".




## 2.3 Choose Target System

Choose the target system to connect to a Beckhoff PLC selecting "Choose Target System...".




Set the system into the Configuration Mode.




## 2.4 Scan for Devices


Right click on “Devices” and select “Scan”.




Select desired network interface card.




When “Scan for boxes” appears  
→ Press YES (Ja).



Select “CNC – Configuration” and Press “OK”.




When “Activate Free Run” appears  
→ Press NO (Nein).




## 2.5 Set Cycle Time

In “SYSTEM→Real-Time” (Tab Settings) set the base time of the CPU.




The cycle tick on the bus can be entered in “MOTION→CNC-Task 1 GEO”. This time can only be greater than or equal to the base time. This is the objects transmission cycle in the “Cyclic Synchronous Position Mode”. Possible values are from 200us to 2ms. Typical is 1ms. Only multiple of 100us are allowed.




## 2.6 Add CNC Channel

Right click on "MOTION→CNC" and "Add New Item...", then select "Channel parameter" and press "OK".



In "MOTION→CNC→Axis\_1" in Register Configuration in "Default Channel" window select "Channel\_1".



## 2.7 PDO-Mapping

### 2.7.1 Required PDO Configuration

Enable output PDO 0x1600

General EtherCAT **Process Data** Plc Startup CoE -Online Online

Sync Manager:

SM	Size	Type	Flags
0	246	MbxOut	
1	246	MbxIn	
2	6	Outputs	
3	10	Inputs	

PDO List:

Index	Size	Name	Flags	SM	SU
0x1A01	6.0	TxPDO 2			0
0x1A10	8.0	TxPDO 3			0
0x1A11	0.0	TxPDO 4			0
0x1A12	10.0	TxPDO 5			0
0x1A13	8.0	TxPDO 6			0
0x1600	6.0	RxPDO 1		2	0
0x1601	0.0	RxPDO 2			0

PDO Assignment (0x1C12):

- 0x1600
- 0x1601
- 0x1611
- 0x1612 (excluded by 0x1600)
- 0x1614 (excluded by 0x1600)

PDO Content (0x1600):

Index	Size	Offs	Name	Type	Default (hex)
0x6040-00	2.0	0.0	Controlword	UINT	
0x607A-00	4.0	2.0	Target Position	DINT	
	6.0				

Enable input PDO 0x1A00

General EtherCAT **Process Data** Plc Startup CoE -Online Online

Sync Manager:

SM	Size	Type	Flags
0	246	MbxOut	
1	246	MbxIn	
2	6	Outputs	
3	10	Inputs	

PDO List:

Index	Size	Name	Flags	SM	SU
0x1A00	10.0	TxPDO 1		3	0
0x1A01	6.0	TxPDO 2			0
0x1A10	8.0	TxPDO 3			0
0x1A11	0.0	TxPDO 4			0
0x1A12	10.0	TxPDO 5			0
0x1A13	8.0	TxPDO 6			0
0x1600	6.0	RxPDO 1			2

PDO Assignment (0x1C13):

- 0x1A00
- 0x1A01
- 0x1A11
- 0x1A12 (excluded by 0x1A00)
- 0x1A13 (excluded by 0x1A00)

PDO Content (0x1A00):

Index	Size	Offs	Name	Type	Default (hex)
0x6041-00	2.0	0.0	Statusword	UINT	
0x6064-00	4.0	2.0	Position Actual Value	DINT	
0x60F4-00	4.0	6.0	Following Error Actual Value	DINT	
	10.n				

### 2.7.2 Add PDO "Modes of Operation"

Select the Output PDO 0x1600 and right click On PDO Content list and click to "Input".

General EtherCAT **Process Data** Plc Startup CoE -Online Online

Sync Manager:

SM	Size	Type	Flags
0	246	MbxOut	
1	246	MbxIn	
2	12	Outputs	
3	10	Inputs	

PDO List:

Index	Size	Name	Flags	SM	SU
0x1A00	10.0	TxPDO 1			3
0x1A01	6.0	TxPDO 2			0
0x1A10	8.0	TxPDO 3			0
0x1A11	0.0	TxPDO 4			0
0x1A12	10.0	TxPDO 5			0
0x1600	6.0	RxPDO 1		2	0
0x1601	0.0	RxPDO 2			0
0x1611	6.0	RxPDO 3			0
0x1612	6.0	RxPDO 4			2

PDO Assignment (0x1C12):

- 0x1600
- 0x1601
- 0x1611
- 0x1612 (excluded by 0x1612)
- 0x1614 (excluded by 0x1612)
- 0x1615 (excluded by 0x1612)

PDO Content (0x1600):

Index	Size	Offs	Name	Type
0x6040-00	2.0	0.0	Controlword	UINT
0x607A-00	4.0	2.0	Target Position	DINT
0x6060	4.0	4.0	Modes of Operation	SINT

Select "0x6060 – Mode of Operation" and click to "OK".

Edit Pdo Entry

Name: Modes of Operation **OK**

Index (hex): 6060 24672 **Cancel**

Sub Index: 0

Data Type: SINT


Bit Length: 8

From Dictionary:


- 0x2000 - S-Curve Profile
- 0x6040 - Controlword
- 0x6060 - Modes of Operation**
- 0x6065 - Following Error Window
- 0x6067 - Position Window
- 0x6073 - Limit I\_Force
- 0x607A - Target Position
- 0x6081 - Profile Velocity
- 0x6083 - Profile Acceleration
- 0x6084 - Profile Deceleration
- 0x60B1 - Velocity Offset
- 0x60B2 - Torque Offset
- 0x50FE-01 - Physical outputs

### 2.7.3 Add PDO "Modes of Operation Display"

Select the Output PDO 0x1A00 and Right click On PDO Content list and click to "Input".




Select "0x6061 – Mode of Operation Display" and click to "OK".




### 2.7.4 Link the added PDO's

In "MOTION→CNC→Axis\_1→Configuration" click to "Link To...", select the desired I/O Box and click to "OK" to refresh and the manually added PDO's will be automatically linked.




## 2.8 Axis Parameter Configuration

CNC-Axis parameter configuration:  
Click on "MOTION→CNC→Axes→Axis\_1" and  
select the "Parameter" register.



Open the parameter list:  
In "Parameter" register click on "Notepad...". The  
parameters can be directly modified, added,  
deleted and saved.



Edit or add the parameters listed in the following  
table according to the corresponding motor:

To do	Parameter Name	Parameter-ID	Parameter Description	LINAX®/ELAX® 1µm	LINAX® 100nm	ROTAX® Rxvp	ROTAX® Rxhq
Edit	kenngr.swe_pos	P-AXIS-00178	Positive software limit switch	Stroke in 0.1µm + 20'000		3'600'000	3'600'000
Edit	kenngr.swe_neg	P-AXIS-00177	Negative software limit switch	(Stroke in 0.1µm + 20'000)*-1		-3'600'000	-3'600'000
Add	kenngr.swe_check	P-AXIS-00705	Switching software limit monitoring off (0) / on (1)	Not needed (Do not add)		0	0
Edit	kenngr.achs_mode	P-AXIS-00015	Operating mode; 1=linear , 4=modulo	0x1	0x1	0x1	0x1
Edit	kenngr.achs_typ	P-AXIS-00018	Axis type; 1=linear axis, 2=rotatory axis, 4=spindle/single axis	1	1	2	2
CNC controlled referencing							
Edit	kenngr.set_refpos_mode	P-AXIS-00278	Homing mode	OFFSET	OFFSET	OFFSET	ABSOLUT
Edit	kenngr.set_refpos_offset	P-AXIS-00279	Offset to the homing position	0	0	0	0
Edit	kenngr.homing_type	P-AXIS-00299	Homing type; CNC_CONTROLLED / DRIVE_CONTROLLED	DRIVE_CONTROLLED	DRIVE_CONTROLLED	DRIVE_CONTROLLED	CNC_CONTROLLED
Edit	kenngr.abs_pos_guelting	P-AXIS-00014	Identification code for absolute path measurement system	0	0	0	1
Add	kenngr.vendor_id	P-AXIS-00535	Select manufacturer-specific procedures for drive controllers	100	100	100	100
Add	kenngr.device_id	P-AXIS-00536	Select device-specific procedures for drive controllers	8	8	8	8
Parameter non-linear velocity profile							
Edit	getriebe[n].slope_profil.a_beschl	P-AXIS-00001	Acceleration at machining feed G1,G2,G3	Application-specific			
Edit	getriebe[n].slope_profil.a_brems	P-AXIS-00002	Deceleration at machining feed G1,G2,G3	Application-specific			
Edit	getriebe[n].slope_profil.a_grenz	P-AXIS-00004	Acceleration at rapid movement G0	Application-specific			
Add	getriebe[n].slope_type	P-AXIS-00270	Effective acceleration profile; 0=step-shaped, 1=trapezoidal	1	1	1	1
Parameter linear velocity profile							
Edit	getriebe[n].lslope_profil.a_stufe_1	P-AXIS-00011	Acc./ dec. of step 1 at machining feed G1,G2,G3	Application-specific			
Edit	getriebe[n].lslope_profil.a_stufe_2	P-AXIS-00012	Acc./ dec. of step 2 at machining feed G1,G2,G3	Application-specific			
Edit	getriebe[n].lslope_profil.vb_stufe_1_2	P-AXIS-00221	Changeover speed between step 1 and 2 at G1,G2,G3	Application-specific			
Edit	getriebe[n].lslope_profil.a_grenz_stufe_1	P-AXIS-00005	Acc./ dec. of step 1 at machining feed G0	Application-specific			
Edit	getriebe[n].lslope_profil.a_grenz_stufe_2	P-AXIS-00006	Acc./ dec. of step 2 at machining feed G0	Application-specific			
Edit	getriebe[n].lslope_profil.vb_grenz_stufe_1_2	P-AXIS-00211	Changeover speed between ramp 1 and 2 at G0	Application-specific			
Permitted axis dynamics							
Edit	getriebe[n].dynamik.vb_max	P-AXIS-00212	Maximum permissible axis velocity	Application-specific			
Edit	getriebe[n].dynamik.a_max	P-AXIS-00008	Maximum permissible axis acceleration	Application-specific			
Edit	getriebe[n].dynamik.a_emergency	P-AXIS-00003	Deceleration for an emergency stop	Application-specific			
Permitted axis velocities							
Edit	getriebe[n].wegaufn	P-AXIS-00233	Path resolution of the measuring system (denominator)	10	1	3'600'000	3'600'000
Edit	getriebe[n].wegaufz	P-AXIS-00234	Path resolution of the measuring system (numerator)	1	1	64'000	120'000
Position lag monitoring							
Add	getriebe[n].load	P-AXIS-00391	Weighting of acceleration feed forward	0.000001	0.00001	0.000001	0.000001
Compensations and monitoring							
Edit	lr_hw[n].vz_stellgr	P-AXIS-00231	Sign reversal of command value	0	0	0	0
Edit	lr_hw[n].vz_istw	P-AXIS-00230	Sign reversal of actual value	0	0	0	0
Feedforward control							
Edit	vorsteuer.vorsteuerung	P-AXIS-00223	Bit-coded feed forward mode	0	0	0	0
Edit	vorsteuer.default_active	P-AXIS-00255	Permanent enabling of the feed forward	0	0	0	0
Edit	antr.acc_reference_value	P-AXIS-00392	Weighting of acceleration feed forward	3.1415	3.1415	17.6709	9.4245
Edit	antr.v_reso_num	P-AXIS-00206	Velocity scaling factor	1	10	64'000	120'000
Edit	antr.v_reso_denom	P-AXIS-00205	Velocity scaling factor	1	1	360'000	360'000
Add	antr.v_time_base	P-AXIS-00207	time base for velocity output, (1= per second)	1	1	1	1

## 2.9 Jerk Value Conversion

The jerk value for the CNC kernel is given in time units as acceleration ramp time.

The formula for the conversion from the jerk in inc/s to the acceleration ramp time in ms is the following:

$$j[\text{ms}] = \frac{a[\text{inc/s}]}{j[\text{inc/s}^2]} \cdot 1'000$$

The same formula for the acceleration ramp time in  $\mu\text{s}$  is the following:

$$j[\mu\text{s}] = \frac{a[\text{inc/s}]}{j[\text{inc/s}^2]} \cdot 1'000'000$$

## 2.10 Demo Project


We cannot provide demo programs for CNC projects. Please contact us for the commissioning of your CNC project with Jenny Science axes.

### 3 Replacing Xvi 75V8 by Xvi 75V8S


To replace a XENAX® Xvi 75V8 with an Xvi 75V8S in an existing project, the following steps must be done.

#### 3.1 ESI XML Installation

The EtherCAT Slave Information XML for the XENAX Xvi 75V8S should always be completely unpacked into the ESI-directory of the EtherCAT master. In TwinCAT 3 these files are located in `\TwinCAT\3.1\Config\Io\EtherCAT`. This ESI file can be downloaded from [www.jennyscience.ch](http://www.jennyscience.ch) under "XENAX Servocontroller->Firmware Bus Module->EtherCAT".




Load ESI file into TwinCAT.  
„TwinCAT→EtherCAT Devices→Reload Device Descriptions“



#### 3.2 Change Type

Change the type of the selected XENAX® controller („Change to Compatible Type...“), then choose the right entry and press OK.



## Notes

This instruction manual contains copyright protected information. All rights are reserved. This document may not be entirely or partially copied, duplicated or translated without the prior consent of Jenny Science AG.

Jenny Science AG grants no guarantee on, or will be held responsible for, any incidents resulting from false information.

Information in this instruction manual might be subject to changes.

Jenny Science AG  
Sandblatte 7a  
CH-6026 Rain

Tel +41 (0) 41 455 44 55  
Fax +41 (0) 41 455 44 50

[www.jennyscience.ch](http://www.jennyscience.ch)  
[info@jennyscience.ch](mailto:info@jennyscience.ch)